



INSTRUCTIONS CM335B

© Panduit Corp. 2009

Installation Instructions

Bracket may be installed for front or rear mounting of the manager.
The orientation indicator should always face the installer



Mounting Footprint

